

>> PAIRING RESET

NOTICE:


The remote control kit (Receiver & Remote Controller) has been paired before ship to retail shops. The following steps are just incasing of signal missing between the Receiver & Remote Controller.

Step 1: Plug in the "Receiver".




Step 2: Turn ON the camera.

Step 3: Press and hold the "Pairing Button", the "Receiver" automatically goes into "Pairing Mode" within 2 seconds. (Please do not release the Pairing button until the step 4 has done).



Step 4: Press and hold the "Shutter Button", the LED light will flash for 3 times once the pairing is initiated.



Caution!



Waterproof Cap



Silicon Grease



O-ring

